

Operation Manual

Battery Tester for 6V and 12V Batteries

62553



Illustration similar, may vary depending on model

Read and follow the operating instructions and safety information before using for the first time.

Technical changes reserved!

Due to further developments, illustrations, functioning steps and technical data can differ insignificantly.

Updating the documentation

If you have suggestions for improvement or have found any irregularities, please contact us.

The information contained in this document may alter at any time without previous notice. It is prohibited to copy or spread any parts of this document in any way without prior written allowance. All rights reserved.

The WilTec Wildanger Technik GmbH cannot be held accountable for any possible mistakes in this operating manual, nor in the diagrams and figures shown.

Even though, the WilTec Wildanger Technik GmbH has undergone biggest possible efforts to ensure that the operating manual is complete, faultless and up to date, mistakes cannot be entirely avoided.

If you should find a mistake or wish to make a suggestion for improvement, we look forward to hearing from you.

Send an e-mail to:

service@wiltec.info

or use our contact form:

<https://www.wiltec.de/contacts/>

The most recent version of this manual in various languages can be found in our online shop via:

<https://www.wiltec.de/docsearch>

Our postal address is:

WilTec Wildanger Technik GmbH
Königsbenden 12
52249 Eschweiler
Germany

Do you wish to pick goods up? Our pick-up address is:

WilTec Wildanger Technik GmbH
Königsbenden 28
52249 Eschweiler
Germany

To shorten the waiting time and allow for a rapid on-site transaction, we ask you to call us previously or placing your order via the webshop.

E-mail: service@wiltec.info

Tel: +49 2403 55592-0

Fax: +49 2403 55592-15

To return orders for exchange, repair or for other purposes, please use the following address. Attention! To allow for a smooth execution of your complaint or return, it is important to contact our customer service team before returning the goods.

Returns Department
WilTec Wildanger Technik GmbH
Königsbenden 28
52249 Eschweiler

E-mail: **service@wiltec.info**

Tel: +49 2403 55592-0

Fax: +49 2403 55592-15

Introduction

Thank you for purchasing this quality product. **To minimize the risk of injury we urge that our clients take some basic safety precautions when using this device. Please read the operation instructions carefully and make sure you have understood its content.**

Keep these operation instructions safe.

Note!

In order to ensure perfect condition and safe operation, the user must observe and comply with the safety and warning instructions in these instructions.

Intended use

The intended use of the device is to test 6V and 12V batteries and accumulators. Any other use than specified is not permitted!

Operating conditions/Safety instructions

- The device may only be operated at the voltage specified for it.
- The operating position of the unit is horizontal and lying on the rubber feet so that the display points upwards.
- It is essential to ensure that the technical specifications given in this manual are observed. Exceeding the specified values may cause damage to the unit or the object to be tested.
- The unit must not be placed in the vicinity of strong HF or magnetic fields, as this may cause the unit to enter an undefined operating state, resulting in incorrect test results.
- Ventilation slits or vents prevent an excessive rise in temperature. Keep materials such as flammable substances or paper away from the unit.
- Do not install the unit in a place where it is exposed to high humidity or vibrations.
- The device is intended for use in dry and clean rooms.
- If condensation forms, wait up to 2 hours for the unit to acclimatise.
- Protect the unit from moisture, splashes of water and the effects of heat.
- The unit must not be used in conjunction with highly flammable and combustible liquids.
- This device may only be used by persons with limited physical, sensory or mental abilities or a lack of experience or necessary expertise if they have been introduced to the use of the device by a competent person familiar with the device and responsible for them, and if they are supervised by this person.
- Children must not use the appliance and must be supervised in its vicinity to ensure that they do not play with the appliance.
- Do not operate the assembly in an environment where flammable gases, vapours or dust are present.
- Repairs may only be carried out by a trained electrician. Only original spare parts may be used for repairs. The use of different spare parts can lead to serious damage to property and personal injury.
- The unit must always be disconnected from the test object before use.

- Before commissioning, always check whether the unit or assembly is suitable for the desired application. In case of any uncertainties or queries, please contact a specialist.

Product description

- Portable
- No external power supply required
- Tests can be completed in a short time
- Impact resistant
- No annual calibration required
- Copper-plated high performance terminal blocks
- Ventilated

With this device the performance of a 6V or 12V battery or accumulators can be measured. The device measures the battery voltage at a current flow of approx. 100 amperes.

The voltage of a "good" and fully charged battery remains relatively constant under load. On the other hand, with a "bad" battery, the voltage collapses quickly. The measurement results are displayed by a precise analogue measuring unit, whose scale is designed for different battery sizes and types.

Operating the Tester

Warning!

When handling lead-acid batteries, highly explosive detonating gas may be produced. This oxyhydrogen gas can be ignited by a spark, cigarette or open flame, causing the battery or accumulator to burst. This causes the sulphuric acid inside to be sprayed and can lead to severe burns.

Therefore, always wear protective goggles when handling lead-acid batteries. Avoid contact of the battery with skin and clothing and wear rubber gloves. Do not smoke in the immediate vicinity of the battery and avoid naked flames. Ensure adequate ventilation.

Discharged lead-acid batteries freeze at extremely low temperatures. Never check a frozen lead-acid battery! Never place the tester or tools on the battery! Never test a lead-acid battery for longer than 10 minutes!

In the event of eye contact with acid, immediately rinse the eyes with clear water for at least 5 minutes and seek medical attention immediately! Under no circumstances use medication or eye drops without doctor's instructions.

Things to know about lead-acid batteries (rechargeable batteries)

- The efficiency of a lead-acid battery decreases as temperatures fall. A fully charged battery has only 40% of the starting power at -18°C that it normally has at 25°C.
- Most batteries break down due to overcharging.
- Heavy discharging does not damage the cells of a battery, but overcharging does.
- A warm battery charges faster than a cold one.
- All batteries are subject to normal self-discharge, which increases with increasing temperature. The self-discharge of maintenance-free batteries is less than that of normal lead-acid batteries.
- Batteries should be stored in as cool a place as possible to keep self-discharge low.

Attention! The battery must not be frozen!

- A fully charged battery freezes at approx. -65°C, a 50% charged battery at -26°C and a 25% charged battery already from -15°C.
- A battery stored in a discharged state "sulphates" and loses its capacity.

Battery load test

1. Connect the battery tester to the battery

If the battery is still installed in a vehicle, switch off the engine of the vehicle and switch off all other consumers in the vehicle. Please note that the on-board voltage can drop very sharply during the test (especially if the batteries are severely discharged or defective), which can trigger an alarm system, for example, or trigger a car radio with anti-theft protection (coding). In any case, make sure that the coding of the radio is deactivated before the load test, or have the code ready to be deactivated.

Connect the black terminal of the test device directly to the negative battery pole (NEG, N, -). Connect the red terminal of the tester directly to the positive battery terminal (POS, P, +).

A battery voltage dependent on the battery's state of charge is now shown on the display instrument of the device. If the displayed voltage is less than 12.4 volts (6.2 volts), the battery should be charged by a load test. If the voltage is still below 12.4 volts (6.2 volts) after charging, it can be assumed that the battery is defective.

If the needle of the display is at the extreme left end of the display, the battery tester is connected with the wrong polarity.

2. Determine the correct measuring range on the scale

Determine the capacity or cold test current of the battery under test. The cold test current is also printed on the battery as "CCA" (Cold Cranking Amps) in the unit "Ampere" (A).

On the scale there is a green area below 12 V which is graduated from 200-1000 CCA. To evaluate the test result, select the scale corresponding to the battery.

If no cold test current is printed on the battery, please use the table below to select the appropriate scale.

Battery capacity	cold test current
36 Ah - 44 Ah	200 A
55 Ah - 66 Ah	400 A
75 Ah - 88Ah	600 A
95 Ah - 110 Ah	800 A
180 Ah-	1000 A

3. Press the test switch for 10 seconds!

Observe the indicator needle of the instrument carefully. Remember where the needle is at the end of the 10 seconds. Assess the battery according to the following battery load analysis.

Battery Load Analysis

Loading test	Battery condition
Ok (green field)	The battery is in good condition and can be fully charged if necessary.
Weak (yellow field)	Battery performance is not satisfying. The battery is either defective or partially discharged. Determine the battery charge level with a hygrometer (measure acid density)
Bad (red field) Needle drops constantly	The battery is faulty (e.g. due to a bad cell). As a counter-check, release the switch and observe the reaction of the voltmeter. If the display returns to 12 V within a few seconds, the battery is defective. If, on the other hand, the battery voltage rises slowly, the battery is probably only very severely discharged.

Assessment of the state of charge via the battery acid density

If the acid density at 27°C is 1.24 kg/dm³ or less, please first charge the battery before carrying out further tests and check the acid density again after one hour of standing time.

Acid density at 27°C in kg/dm ³	State of charge	Actions
1,25 - 1,28	Charged	Test possible
1,20 - 1,24	Half charged	Charging recommended
Lower as 1,20	Poorly charged	Load immediately

The acid density should be the same in all cells of a good battery. Maximum permissible tolerance between highest and lowest measured value of the 6 cells: 0.03 kg/dm³.

If the acid density is the same in all cells but less than 1.25 kg/dm³, please charge the battery.

Temperature compensation

Due to the chemical reactions that take place in a lead-acid battery, the test results depend on the battery temperature. In order to obtain the most accurate test results possible, compensation must be carried out from approx. -8°C.

This is achieved by subtracting 50 amperes of cold test current from the printed value of the battery's cold test current for each -10°C cold. This means that at -20°C 100 A and at -30°C 150 A cold test current are subtracted.

Example: If the printed battery cold test current is 500 A and the test is carried out at -18°C, use the 400 CCA scale.

Testing the charging system

With the help of the battery tester, many small general faults in the charging circuit can be quickly and easily detected.

The motor should be at normal operating temperature for testing.

- Connect the battery tester to the vehicle battery with the correct polarity.
- Start the engine and run it at a speed of at least 1500 rpm.
- Do not operate the test switch on the unit!
- Read the display when the electrical consumers (light, fan, etc.) are switched off. The needle should be in the green area (OK) at approx. 14 volts.
- When the electrical consumers are switched on, the needle should remain in the green area.
- If the needle is in the red area above or below the green area, this indicates a fault in the charging circuit (e.g. defective charge controller).

Testing the starter motor

This test detects excessive current consumption of the starter motor. Excessive current consumption of the starter motor leads to an overload of the battery and thus shortens its life. This test should only be carried out if the battery load test was previously completed with "OK".

- For testing the motor should have normal operating temperature.
- Connect the test device to the vehicle battery with the correct polarity.
- Press the test button for max. 10 seconds and note down the voltage value while keeping the test button pressed.
- Disconnect the engine ignition cable from the spark plug so that the engine does not start when starting.
- Now try to start the engine. Make a note of the voltage during the starting procedure.
- Compare the two voltages with the yellow table printed in the display (STARTER TEST). The upper row of the table refers to the "LOAD VOLTS" i.e. the voltage measured during the load test with the unit. Below this voltage value the table shows the corresponding minimum starting voltage (MIN. CRANK VOLTS).

Example: You measure a voltage of 10.4 V during the load test and the voltage collapses to 9.5 V during starting. According to the table a starting voltage of up to 8.2 V is acceptable. The starter engine is ok. If a starting voltage of less than 8.2 V is measured, a short circuit in the starter, a fixed bearing in the starter etc. could be the reason for excessive power consumption.

Technical Data

Dimensions	290 x 110 x 75 mm (l x w x h)
Ampere range	300 – 1000 A
Testing procedure	100 A load current
Cable length	2 x 30 cm
Miscellaneous	2 clamping pliers with 30 cm supply cable

Malfunctions on the device

If it can be assumed that safe operation is no longer possible, the device must be taken out of operation and secured against inadvertent operation.

This applies if:

- the unit shows visible damage.
- the device is no longer functional.
- parts of the unit are loose or loose.
- the connecting cables show visible damage.

Disposal regulations

EU guidelines regarding the disposal of scrap electric appliances (WEEE, 2012/19/EU) were implemented in the law related to electrical and electronic equipment and appliances.

All WilTec electric devices that fall under the WEEE regulations are labelled with the crossed-out wheeled waste bin logo. This logo indicates that this electric equipment must not be disposed with the domestic waste.

The company WilTec Technik GmbH has been registered in the German registry EAR under the WEEE-registration number DE45283704.

Disposal of used electrical and electronic appliances (intended for use in the countries of the European Union and other European countries with a separate collection system for these appliances).

The logo on the article or on its packaging points out that this article must not be treated as normal household waste but must be disposed to a recycling collection point for electronic and electrical waste equipment. By contributing to the correct disposal of this article you protect the environment and the health of your fellow men. Environment and health are threatened by inappropriate disposal.



Materials' recycling helps reduce the consumption of raw materials.

Additional information on recycling this article can be provided by your local community, municipal waste disposal facilities or the store where you purchased the article.

Address:
WilTec Wildanger Technik GmbH
Königsbenden 12 / 28
D-52249 Eschweiler

Important notice:

The reprint or reproduction, even of excerpts, and any commercial use, even in part of this instructions manual require the written permission of WilTec Wildanger Technik GmbH.