




blumfeldt

Schaukelstuhl



10030615 10030616 10030617 10030618

Sehr geehrter Kunde,

wir gratulieren Ihnen zum Erwerb Ihres Schaukelstuhls. Lesen Sie die folgenden Hinweise sorgfältig durch und befolgen Sie diese, um möglichen Schäden vorzubeugen. Für Schäden, die durch Missachtung der Hinweise und unsachgemäßen Gebrauch entstehen, übernehmen wir keine Haftung.

Artikel

Artikelnummern 10030615 10030616 10030617 10030618

Schaukelstuhl

Hinweise zur Verwendung und zur Sicherheit

Sicherheit

- Dieser Stuhl ist für ein Gewicht von höchstens 150 kg geeignet.
- Stellen Sie sich nicht auf den Stuhl.
- Der Stuhl darf nur auf einen festen, ebenen Boden gestellt werden. Gewährleisten Sie, dass der Rahmen auf dem Boden aufliegt.
- Halten Sie kleine Teile außerhalb der Reichweite von Kindern.


Reinigung und Pflege

- Wischen Sie den Stuhl mit einem feuchten Lappen.
- Verwenden Sie keine Scheuermittel und scharfen Reiniger.

Lieferumfang

A

1 x




E

6 x



B

2 x




F

6 x



C

2 x



G

4 x



D

10 x




H


2 x




Montage



2



3



Ziehen Sie die Schrauben erst richtig fest, wenn das letzte Teil montiert wurde.

Hersteller: Chal-Tec GmbH, Wallstraße 16, 10179 Berlin, Deutschland

Dear Customer,

Congratulations on purchasing this rocking chair. Please read this manual carefully and take care of the following hints on installation and use to avoid technical damages. Any failure caused by ignoring the items and cautions mentioned in the operation and installation instructions are not covered by our warranty and any liability.

Item

Item number **10030615 10030616 10030617 10030618**

Wave Rocker

Hinweise zur Verwendung und zur Sicherheit

Safety:

- This product is intended for a maximum weight of 330 lbs. Do not exceed.
- Do not stand on the product.
- This product should only be used on a firm, level surface. Ensure the frame remains in contact with the surface.
- Keep small parts out of reach of children.
- Do not use the product if parts are missing, damaged or worn.

Before You Start

- Unwrap all packaging materials.
- Make sure you have all of the parts listed.


Care Instructions

- To clean, wipe with a sponge and warm soapy water then wipe with a dry, clean cloth. Do not use solvent based cleaners as they can bleach or damage the product.
- Never use a pressure hose or washer to clean the product. Never use scourers, abrasive or chemical cleaner.
- We recommend furniture covers to protect your product when not in use. During bad weather and winter months the product should be stored in a cool, dry place. Before storage, ensure that it is clean and dry.
- The frame is aluminum.
- Avoid bringing the fabric into contact with sharp objects.

Scope of Supply

A

1 x




E

6 x



B

2 x




F

6 x



C

2 x



G

4 x



D

10 x






H

2 x




Installation


1



2



3



Do not tighten bolts fully until last part is attached.

Producer: Chal-Tec GmbH, Wallstraße 16, 10179 Berlin, Germany