


INSTRUCTION MANUAL



Impact 70 SL

<p>1.</p> <p>OFF</p>	<p>2.</p> <p>Ø100mm</p>	
<p>3.</p> <p>INPUT: AC220-240V</p>	<p>4.</p> <p>8mm</p>	<p>6.</p>
	<p>5.</p>	<p>Overall Sizes:</p> <p>100 142 98</p>
<p>6.</p>	<p>ON</p>	