







USE INSTRUCTION HANDBOOK
















ISTRUZIONI DI MONTAGGIO











LONDON







A1	 ST4x30mm	x6	D2		x1
A2		x6	D3		x1
B		x2	E1		x1
C1		x4	E2		x1
C2		x4	H1		x2
C3	 ST4x12mm	x4	H2		x2
D	 ST4x30mm	x4	G		x4
D1		x4			











	C1 x4
	C2 x4
	C3 ST4x12mm x4















D
ST4x30 X4


D1
x4

D2
X1

D3
X1







H1



x2

H2



x2

