






Montageanleitung







-
- Assembly instructions
 - Notice de montage
 - Montagehandleiding
 - Návod na montáž







- Instrucțiune de montaj
- Navodila za namestitev
- Installationstruktioener

Ersatzteilbestellung
 Ordering spare parts
 Achat de pièces détachées
 Bestelling van reserveonderdelen




















1




2




3




1



2




3




4

1-1




1-2




2-1





2-2




5






6








Ansicht von innen / inside view









7




8





9









10




Ansicht von innen
inside view




11




12




13




14




1-1




1-2






2-1




2-2




15





1-1



1-2







Kontrollbeleg Control Receipt

Prüfnummer / Inspection number



Service
Am Lindhövel 1
59846 Sundern
Deutschland / Germany / Allemagne / Duitsland



Allgemeine technische Probleme:
Telefon 02935 / 96 53 444



E-Mail:
onlineservice@schulte.de