
# COSTWAY ITEM:CL10945

#### **INSTRUCTION MANUAL**

## Parts List



# Store your brooms, mops & more with this Broom & More Holder.

### To install:

- Place the broom and more holder with hooks upward.
- Place the broom and more holder on a flat wall.
- Insert the tip of a pencil into each mounting hole to mark the locations for mounting thehardware.
- Select a 1/4"(6.35mm) drill bit from the drill bit set to match the diameter of the hollow wall anchor.Drill a hole at each mounting location with the 1/4" (6.35mm) drill bit secured in the drill.Drill a 1 1/4"(3cm) deep hole.
- Tap the hollow wall anchor into each drilled hole with a hammer.
- Align the mounting holes of the broom and more holder.
   Thread a screw into each hollow wall anchor.
- Tighten each screw with a Phillips-head screwdriver to complete the installation of the broom and more holder.

**TO CLEAN:**Wipe with a soft damp cloth.



- For indoor use only.
- Do not place large or heavy objects on the broom and more holder.
- Do not overload the holder with items.
- Do not use for any other purpose other than intended use.

THIS IS NOT A TOY.FOR ADULT USE ONLY.
KEEP OUT OF REACH OF CHILDREN.
READ AND SAVE THESE INSTRUCTIONS

