AirMaxPro Portable Electric Air Compressor | User Manual

Pompe à air portative pour vélo Electric Portable Electric Air Compressor

Pompa per bicicletta Elettrica Portatile Electric Portable Electric Air Compressor

Bomba de aire Electrica Portátil Electric Air Compressor

Manual of AirMaxPro Electric Portable Electric Air Compressor

Electric Tragbare Elektrische Luftkompressor | Tragbarer Luftkompressor

Protezione portatile elettrica Electric Portable Electric Air Compressor

Русский 俄语 ПО. ЭЛЕКТРИЧЕСКИЙ ДЫХАТЕЛЬНЫЙ АППАРАТ

Español 西班牙语 | Electric Portable Electric Air Compressor

Manual de AirMaxPro Electric Portable Electric Air Compressor

Electric Tragbare Elektrische Luftkompressor | Tragbarer Luftkompressor

Manual de AirMaxPro Electric Portable Electric Air Compressor

Français 法语 | Electric Portable Electric Air Compressor

Electric 电动打气筒 | 使用说明书 zh

العربية 阿拉伯语 | Electric Portable Electric Air Compressor

Original instructions

EN

Safety Instructions

WARNING

Carefully read all safety warnings, instructions, illustrations and specifications provided with this product. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury. The term "battery" in the warnings refers to your product battery or the battery you use in the product. Save all warnings and instructions for future reference. The term "battery charger" in the warnings refers to your battery charger (corded) or battery charging accessory (cordless) for your product. Read and follow all safety rules and instructions before using this product.

Product Overview

Congratulations on your purchase! Please read carefully the following instructions before operating your product. Proper use will result in your enjoying your product for many years to come. Keep these instructions handy for future reference.

Charging
- Fully charge the battery before first use.
- Charge the battery every 3 months if not in use.
- Use only the charger provided with this product.
- Do not charge in extreme temperature.
- Unplug the charger when not in use.

Storage
- Fully charge before storage.
- Do not store in extreme temperature.
- Keep the product away from children and pets.

How To Use

Battery Level Indicator in Charging

Charging

- Flashing red: 0 % - 25 %
- Flashing yellow: 25 % - 50 %
- Flashing green: 50 % - 75 %
- Solid green: 75 % - 100 %

Fully charged

- Solid green: 100 %

Turning on/off

Press the power button once to turn the device on. Press the power button again to turn the device off.

Connecting the light source on bicycle and other

Bicycle

- Insert the light source into the bicycle mount and rotate it clockwise to lock it in place.
- To remove the light source, rotate it counterclockwise and pull it out.

Other

- Use the nozzle adapter and power nozzle to connect the light source to other devices.

Connecting the light source on a power nozzle

Power nozzle

- Insert the light source into the power nozzle and rotate it clockwise to lock it in place.
- To remove the light source, rotate it counterclockwise and pull it out.

Inflating the presta valve

- Remove the dust cap from the presta valve.
- Tighten the nozzle adapter onto the presta valve by rotating it clockwise to lock it in place.
- Turn on the device and start inflating.
- Turn off the device when the tire is inflated to the desired pressure.
- Remove the nozzle adapter from the presta valve by rotating it counterclockwise and pull it out.
- Replace the dust cap on the presta valve.

Disconnecting the air pressure

- Turn off the device and remove the nozzle adapter from the presta valve.
- Press the release button on the nozzle adapter to release the air pressure.

Disconnecting the air pressure on presents

- Turn off the device and remove the nozzle adapter from the presta valve.
- Press the release button on the nozzle adapter to release the air pressure.

Inflating the schrader valve

- Remove the dust cap from the schrader valve.
- Tighten the nozzle adapter onto the schrader valve by rotating it clockwise to lock it in place.
- Turn on the device and start inflating.
- Turn off the device when the tire is inflated to the desired pressure.
- Remove the nozzle adapter from the schrader valve by rotating it counterclockwise and pull it out.
- Replace the dust cap on the schrader valve.

Disconnecting the air pressure

- Turn off the device and remove the nozzle adapter from the schrader valve.
- Press the release button on the nozzle adapter to release the air pressure.

Disconnecting the air pressure on presents

- Turn off the device and remove the nozzle adapter from the schrader valve.
- Press the release button on the nozzle adapter to release the air pressure.

Inflating presta valve

- Remove the dust cap from the presta valve.
- Tighten the nozzle adapter onto the presta valve by rotating it clockwise to lock it in place.
- Turn on the device and start inflating.
- Turn off the device when the tire is inflated to the desired pressure.
- Remove the nozzle adapter from the presta valve by rotating it counterclockwise and pull it out.
- Replace the dust cap on the presta valve.

Disconnecting the air pressure

- Turn off the device and remove the nozzle adapter from the presta valve.
- Press the release button on the nozzle adapter to release the air pressure.

Disconnecting the air pressure on presents

- Turn off the device and remove the nozzle adapter from the presta valve.
- Press the release button on the nozzle adapter to release the air pressure.

Inflating schrader valve

- Remove the dust cap from the schrader valve.
- Tighten the nozzle adapter onto the schrader valve by rotating it clockwise to lock it in place.
- Turn on the device and start inflating.
- Turn off the device when the tire is inflated to the desired pressure.
- Remove the nozzle adapter from the schrader valve by rotating it counterclockwise and pull it out.
- Replace the dust cap on the schrader valve.

Disconnecting the air pressure

- Turn off the device and remove the nozzle adapter from the schrader valve.
- Press the release button on the nozzle adapter to release the air pressure.

Disconnecting the air pressure on presents

- Turn off the device and remove the nozzle adapter from the schrader valve.
- Press the release button on the nozzle adapter to release the air pressure.

Inflating

- Turn on the device.
- Connect the nozzle adapter to the valve.
- Inflate.
- Turn off the device.
- Disconnect the nozzle adapter from the valve.

Disconnecting the air pressure

- Turn off the device and remove the nozzle adapter from the valve.
- Press the release button on the nozzle adapter to release the air pressure.

Disconnecting the air pressure on presents

- Turn off the device and remove the nozzle adapter from the