



Towel Rail Installation


- · review instructions carefully before installation
- · installation should be completed by a suitably qualified person
- · please dispose of packaging in a responsible manner




















After installation . . .

- · Use a screwdriver to open the air vent, open the valve and let the water rush into the towel warmer. Check all connections for leaks.
- · Once water overflows from the air vent, there is no air in the tube.
- · Use a screwdriver to close the air vent, turn on the valve and the towel warmer is ready for use.

After care . . .

 Classic towel warmers are made from steel with chrome plating, and should not be cleaned with corrosive or scouring cleaning agents.

Please note . . .

• This product can only be used at PN ≤ 0.3 MPa (10g/cm², 3Bar), It should only be filled with water, and at a temperature below 100°C (212°F). See table below for installation requirements.

If the temperature exceeds 48°C (or 120°F), please install a warning sign near the product to avoid burning and scolding accidents.

Fill ³ / ₄ Full	Pressure	Temperature	Comments
water only	PN≤0.3Mpa	0° C < t ≤ 100°C	If ambient temperature drops below1°C, drain out the water to prevent freezing.

Check out our full range of Bathroom Accessories

Heated Towel Rails
Bathroom Extractor Fans
Bathroom Lighting

Bathroom Accessory Sets

Shower Seats

Grab Rails

Shower Curtains

Toilet Brushes

Bathroom Cleaning Products

Wall Mounted Bathroom Accessories

Robe Hooks

Bathroom Tumblers

Toilet Roll Holders

Soap Dishes

Towel Rings

Shower Caddies

Bathroom Mirrors

Standard Bathroom Mirrors

LED Bathroom Mirrors

Shaving Mirrors

